

How to use

Heavy Duty Spray Cleaner / Degreaser



READY-TO-USE LABEL (Diluted 1:64)

DIRECTIONS FOR USE: Apply cleaner solution directly onto the surface to be cleaned. Allow solution to penetrate grease and soils. If needed, brush with a stiff bristle brush. Rinse if necessary.

KEEP OUT OF REACH OF CHILDREN. **SUBSTITENCIA FUERA DEL ALCANCE DE NIÑOS.**
Palabra de advertencia

Precautionary statement **Prevenção:** Mantenha boas práticas de higiene industrial.

Response: Wash hands after handling. **Resposta:** Lave-se as mãos depois do uso.

Storage: Store away from incompatible materials. **Armazenamento:** Conserve-se afastado de materiais incompatíveis.

Disposal: Dispose of contents/container in accordance with local/regional/national/international regulations. **Eliminação:** Eliminação de conteúdos / contêineres em consonância com os regulamentos locais / regionais / nacionais / internacionais pertinentes.

This product is not known to be a "Hazardous Chemical" as defined by the OSHA Hazard Communication Standard, 29 CFR 1910.1200.

Additional safety measures: Este produto no se considera perigoso según la Norma de Comunicación de Peligros (Hazard Communication Standard) de OSHA, 29 CFR 1910.1200.

Read the entire label and SDS before using this product, and for additional first aid measures. SDS for this product is available on the web at www.nclonline.com. **Medidas adicionales de primeros auxilios:** Lea toda la etiqueta y SDS antes de usar este producto, así como medidas adicionales de primeros auxilios. SDS para el artículo está disponible en la web en www.nclonline.com.



DUAL-BLEND EQUIPMENT

DIRECTIONS:

Chemical Selector Dial

1. Turn the chemical selector dial to the desired chemical position, indicated by the directional arrow
2. Dispense chemical by either activating the bottle fill lever or bucket fill button.
3. For rinse water, point the dial straight down at the water symbol. This is not potable water, do not drink

Bottle Fill

1. Slide the bottle tube inside a the spray bottle and raise the bottle to engage the u-shaped lever of the bottle fill assembly
2. To stop filling, lower the bottle and the lever will disengage
3. Be careful when removing the spray bottle so as to not splash residual chemical

Bucket Fill

1. To start the flow of diluted chemical, press button on unit above selector dial
2. For continuous flow, twist button clockwise
3. To disengage, release button or twist button counterclockwise

NOTE: The DUAL-BLEND® bottle is designed for use with the DUAL-BLEND® Wall Dispenser and the DUAL-BLEND® Portable Dispensing Unit. Dilution tips built into the product containers provide precise, accurate dilution for every product, every time, regardless of dispensing equipment chosen.

DIRECTIONS FOR USE:

FOR SPRAY & WIPE CLEANING

APPLICATIONS: Fill a properly labeled quart container with HEAVY DUTY SPRAY CLEANER/DEGREASER solution from the DUAL-BLEND® Dispensing Unit at a dilution rate of 1:64 (2 oz per gallon) and tighten trigger sprayer. Use cold tap water only. Apply cleaner solution directly onto the surface to be cleaned. Allow solution to penetrate grease and soils. If needed, brush with a stiff bristle brush. Rinse if necessary.

NOTE: Improper use or dilution may cause damage to surfaces and my increase the risk of health effects.



DISPOSE OF UNUSED PRODUCT IN ACCORDANCE WITH LOCAL, STATE AND FEDERAL REGULATIONS - PLEASE RECYCLE CONTAINER

PPE INFORMATION: Respiratory protection is generally not required. No special ventilation is normally required. The use of safety glasses is recommended. No other protective equipment is required.

